

MAINTENANCE

page		page	
92	MAINTENANCE	132	BRAKELIGHT SWITCH ADJUSTMENT
92	THE IMPORTANCE OF MAINTENANCE	133	BULB REPLACEMENT
93	MAINTENANCE SAFETY	139	CLEANING
94	SAFETY PRECAUTIONS	144	STORAGE GUIDE
95	MAINTENANCE SCHEDULE	144	STORAGE
98	TOOL KIT	146	REMOVAL FROM STORAGE
99	SERIAL NUMBERS	147	SPECIFICATIONS
100	COLOUR LABEL	151	CATALYTIC CONVERTER
101	ENGINE OIL	152	NOISE CONTROL SYSTEM (AUSTRALIA ONLY)
106	THROTTLE OPERATION		
107	IDLE SPEED		
108	COOLANT		
109	DRIVE CHAIN		
115	DRIVE CHAIN SLIDER		
116	FRONT AND REAR SUSPENSION INSPECTION		
117	SIDE STAND		
118	WHEEL REMOVAL		
125	BRAKE PAD WEAR		
127	BATTERY		
129	FUSE REPLACEMENT		