

(Ref.No.) Description	Function
(11) Multi-function display	The display includes the following functions; This display shows the initial display (page 18).
Low oil pressure indicator/High coolant temperature indicator/ PGM-FI indicator/ HESD indicator	Lights the low oil pressure indicator and/or high coolant temperature indicator and/or PGM-FI indicator and/or HESD indicator to notify that there is abnormality in engine oil pressure and/or coolant temperature and/or PGM-FI (Programmed Fuel Injection) system and/or HESD (Honda Electronic Steering Damper) when the malfunction indicator (MIL) lights. See pages 21 – 25 .
Speedometer	Shows riding speed (page 26).
Digital clock	Shows hour and minute (page 29).
Coolant temperature meter	Shows coolant temperature (page 20).