

5. Tyres—check condition and pressure (pages 51 – 56 ).
6. Drive chain—check condition and slack (page 109 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions (page 106).
8. Lights and horn—check that headlight, brake/tail light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 63 ).
10. Side stand ignition cut-off system—check for proper function (page 117 ).