

Odometer/Tripmeter

The odometer (1) shows accumulated mileage.

The tripmeter shows mileage per trip.

There are two tripmeters, tripmeter A (2) and tripmeter B (3).


Push control button A (4) to select the odometer, tripmeter A or tripmeter B.

< E type only >

The unit of the indication depends on the unit which you set up (page 34).

The tripmeter A can be displayed from 0 to 999.9 kilometers (miles). The tripmeter B can be displayed up to 9,999.9 kilometers (miles). If the display exceeds 999.9 or 9,999.9 kilometers (miles), it will return to 0 automatically.

The odometer can be displayed from 0 to 999,999 kilometers (miles).



- (1) Odometer
- (2) Tripmeter A
- (3) Tripmeter B
- (4) Control button A