

5. Tyres—check condition and pressure (pages 59 – 64 ).
6. Drive chain—check condition and slack (page 112 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions (page 110).
8. Lights and horn—check that headlight, brake/taillights, position light, license light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 71 ).
10. Side stand ignition cut-off system—check for proper function (page 120 ).