


### Initial Display

When the ignition switch is turned ON, the multi-function display (1) will temporarily show all the modes and digital segments so that you can make sure the liquid crystal display is functioning properly.

The unit “mph” ( 2 ), “mile” ( 3 ), and “gal” ( 4 ) will be displayed only for E type.

Digital clock (5) will reset if the battery is disconnected.



- (1) Multi-function display
- (2) “mph”
- (3) “mile”
- (4) “gal”
- (5) Digital clock