

Odometer/Tripmeter

The odometer (1) shows accumulated mileage.

The tripmeter shows mileage per trip.

There are two tripometers, tripmeter A (2) and tripmeter B (3).


Push control button A (4) to select the odometer, tripmeter A or tripmeter B.

〈E type only〉

The unit of the indication depends on the unit which you select (page 34).

Tripmeter A can be displayed from 0 to 999.9 kilometers (miles). Tripmeter B can be displayed up to 9,999.9 kilometers (miles). If Tripmeter A exceeds 999.9 kilometers (miles), or if Tripmeter B exceeds 9,999.9 kilometers (miles), it will return to 0 automatically.

The odometer can be displayed from 0 to 999,999 kilometers (miles).



(1) Odometer

(2) Tripmeter A

(3) Tripmeter B

(4) Control button A