



4. Press control button B. The minute display will start blinking.



5. To set the minute, press control button A until the desired minute. The minute display will return to “00” when “60” is reached without affecting the hour display.
- The time advances by one minute, each time the button is pressed.
 - The time advances fast when the button is pressed and held.



6. To end the adjustment, press control button B or turn the ignition switch OFF. The display will stop flashing automatically and the adjustment will be cancelled if the button is not pressed for about 30 seconds.

The clock will be reset 1:00 if the battery is disconnected.