

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	94	
* AIR CLEANER		NOTE (2)					R		R	—	
SPARK PLUGS					EVERY 24,000 km (16,000 mi) I, EVERY 48,000 km (32,000 mi) R					89-93	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	85-88	
ENGINE OIL FILTER			R		R		R		R	86-88	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	95	
RADIATOR COOLANT		NOTE (3)			I		I		R	31-32	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	