MAINTENANCE

Page page 59 MAINTENANCE 94 Brake Pad Wea	r
OF THE TENTE OF TH	.1
60 Maintenance Schedule 96 Brake System In	nspection
63 Tool Kit 97 Battery	-
64 Serial Numbers 99 Fuse Replacement	ent
65 Colour Label 102 Stoplight Switch	h Adjustment
66 Maintenance Precautions 103 Bulb Replacement	ent
67 Engine Oil	
71 Spark Plugs 109 CLEANING	
75 Throttle Operation	
76 Idle Speed 111 STORAGE GUIDI	E
77 Drive Chain 111 Storage	
83 Drive Chain Slider 113 Removal from S	Storage
84 Front and Rear Suspension	
Inspection 114 SPECIFICATIONS	S
85 Side Stand	
86 Wheel Removal 118 NOISE CONTROL (AUSTRALIA ON	