

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Coolant temperature gauge
- (2) Fuel gauge
- (3) Digital clock
- (4) Left turn signal indicator
- (5) PGM-FI indicator
- (6) High beam indicator
- (7) Speedometer
- (8) Odometer
- (9) Tripmeter
- (10) Low oil pressure indicator
- (11) Neutral indicator
- (12) Right turn signal indicator
- (13) Tachometer
- (14) Tachometer red zone
- (15) Immobilizer system indicator
(Except U, BR)
- (16) Tripmeter reset knob
- (17) Fuel indicator

