

(Ref. No.) Description	Function
(1) Coolant temperature gauge	Shows coolant temperature (see page 13).
(2) Fuel gauge	Shows approximate fuel supply available (see page 14).
(3) Digital clock	Shows hour and minute (page 15).
(4) Left turn signal indicator	Flashes when the left turn signal operates.
(5) PGM - FI indicator (red)	<p>Lights when there is any abnormality in the PGM - FI (Programmed Fuel Injection) system. Should also light for a few seconds and then go off when the ignition switch is turned ON and engine stop switch is at \bigcirc (RUN).</p> <p>If it comes on at any other time, reduce speed and take the motorcycle to your Honda dealer as soon as possible.</p>