| page | | page | |
|-----------|------------------------------|------|---------------------|
| 54 | FEATURES | 63 (| OPERATION |
| | (Not required for operation) | 63 | PRE-RIDE INSPECTION |
| 54 | STEERING LOCK | 65 | STARTING THE ENGINE |
| 55 | SEAT | 68 | RUNNING-IN |
| 56 | HELMET HOLDER | 69 | RIDING |
| 57 | DOCUMENT BAG | 71 | BRAKING |
| 58 | STORAGE COMPARTMENT FOR | 72 | PARKING |
| | U-SHAPED ANTI-THEFT LOCK | 73 | ANTI-THEFT TIPS |
| 59 | FRONT COWL | | |
| 60 | INNER COWL | | |
| 61 | INNER PANEL | | |
| 62 | HEADLIGHT AIM VERTICAL | | |
| | ADJUSTMENT | | |