

ITEM	FREQUENCY	WHICHEVER →		ODOMETER READING [ NOTE (1) ]								Refer to Page	
		COMES	x 1,000 km	1	6	12	18	24	30	36			
		FIRST ↓	x 1,000 mi	0.6	4	8	12	16	20	24			
	NOTE	MONTH		6	12	18	24	30	36				
				1. EVERY 1,000km (600mi)								74	
	DRIVE CHAIN					I			I		I	80	
	DRIVE CHAIN SLIDER					I			I		I	80	
	BRAKE FLUID	NOTE (3)				I		I	R		I	R	18
	BRAKE PAD WEAR					I		I	I		I	I	90
	BRAKE SYSTEM					I			I		I	18, 90	
*	BRAKE LIGHT SWITCH							I			I	—	
*	HEADLIGHT AIM							I			I	—	
	CLUTCH SYSTEM					I		I	I		I	22	
	SIDE STAND							I			I	82	
*	SUSPENSION							I			I	81	
*	NUTS, BOLTS, FASTENERS					I			I		I	—	
**	WHEELS/TYRES							I			I	—	
**	STEERING HEAD BEARINGS					I			I		I	—	