MAINTENANCE

| page | | page | |
|------|-----------------------------|------|-------------------------|
| 64 | MAINTENANCE | 112 | CLEANING |
| 65 | Maintenance Schedule | | |
| 68 | Tool Kit | 115 | STORAGE GUIDE |
| 69 | Serial Numbers | 115 | Storage |
| 70 | Colour Label | 117 | Removal from Storage |
| 71 | Maintenance Precautions | | |
| 72 | Air Cleaner | 118 | SPECIFICATIONS |
| 73 | Engine Oil | | |
| 77 | Spark Plugs | 122 | RADIO TYPE APPROVALS OF |
| 81 | Throttle Operation | | IMMOBILIZER SYSTEM |
| 82 | Idle Speed | | (Except U,MX,BR) |
| 83 | Drive Chain | | |
| 89 | Drive Chain slider | 123 | NOISE CONTROL SYSTEM |
| 90 | Front and Rear Suspension | | (AUSTRALIA ONLY) |
| | Inspection | | |
| 91 | Side Stand | | |
| 92 | Wheel Removal | | |
| 99 | Brake Pad Wear | | |
| 101 | Battery | | |
| 103 | Fuse Replacement | | |
| 106 | Stoplight Switch Adjustment | | |
| 107 | Bulb Replacement | | |
| | • | | |