


FEATURES (Not required for operation)

STEERING LOCK

To lock the steering, turn the handlebars all the way to the left or right, turn the key (1) to LOCK while pushing in. Remove the key. To unlock the steering, turn the key to OFF while pushing in.

▲WARNING

*** Do not turn the key to LOCK while riding the motorcycle; loss of vehicle control will result.**



(1) Ignition key

- (A) Push in
- (B) Turn to LOCK
- (C) Turn to OFF