

MAINTENANCE

page

84 MAINTENANCE

- 84 THE IMPORTANCE OF MAINTENANCE
- 85 MAINTENANCE SAFETY
- 86 SAFETY PRECAUTIONS
- 87 MAINTENANCE SCHEDULE
- 90 TOOL KIT
- 91 SERIAL NUMBERS
- 92 COLOUR LABEL
- 93 ENGINE OIL
- 100 SPARK PLUGS
- 105 THROTTLE OPERATION
- 106 IDLE SPEED
- 107 COOLANT
- 108 DRIVE CHAIN
- 114 DRIVE CHAIN SLIDER
- 115 FRONT AND REAR SUSPENSION INSPECTION
- 116 SIDE STAND
- 117 WHEEL REMOVAL
- 124 BRAKE PAD WEAR
- 126 BATTERY
- 128 FUSE REPLACEMENT

page

- 131 STOPLIGHT SWITCH ADJUSTMENT
- 132 BULB REPLACEMENT

138 CLEANING

143 STORAGE GUIDE

- 143 STORAGE
- 145 REMOVAL FROM STORAGE

146 SPECIFICATIONS

150 CATALYTIC CONVERTER

151 NOISE CONTROL SYSTEM (AUSTRALIA ONLY)