

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Fuel gauge and coolant temperature display
- (2) Left turn signal indicator
- (3) Immobilizer system (HISS) indicator
< Except MX type >
- (4) Neutral indicator
- (5) Tachometer
- (6) Tachometer red zone
- (7) Tachometer red zone indicator
- (8) Malfunction indicator (MIL)
- (9) High beam indicator
- (10) Right Turn signal indicator
- (11) Multi-function display
- (12) RESET button
- (13) ADJ button

