

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								108
DRIVE CHAIN SLIDER					I			I		I	114
BRAKE FLUID		NOTE (3)		I	I	R	I	I	R		36
BRAKE PAD WEAR				I	I	I	I	I	I		124
BRAKE SYSTEM			I		I		I		I		36, 124
* BRAKE LIGHT SWITCH					I		I		I		—
* HEADLIGHT AIM					I		I		I		71
CLUTCH SYSTEM			I	I	I	I	I	I	I		39
SIDE STAND					I		I		I		116
* SUSPENSION					I		I		I		115
* NUTS, BOLTS, FASTENERS			I		I		I		I		—
** WHEELS/TYRES					I		I		I		—
** STEERING HEAD BEARINGS			I		I		I		I		—