

SPARK PLUGS

Refer to the Safety Precautions on page 85 .

Recommended plugs:

Standard:

IMR9C-9HES (NGK) or
VUH27D (DENSO)

NOTICE

Never use a spark plug with an improper heat range. Severe engine damage could result.

This motorcycle uses the spark plugs that have an iridium coated center electrode. Be sure to observe the following when servicing the spark plugs.

- Do not clean the spark plug. If the electrode is contaminated with accumulated objects or dirt, replace the spark plug with a new one.
- To check the spark plug gap, use only a “wire-type feeler gauge.” To prevent damaging the iridium coating of the center electrode, never use a “leaf-type feeler gauge.”
- Do not adjust the spark plug gap. If the gap is out of specification, replace the spark plug with a new one.

To inspect or replace the spark plugs, use an appropriate spark plug wrench or see your Honda dealer.