

## **Load Limits**

Following are the load limits for your motorcycle:

### **Maximum weight capacity:**

189 kg (417 lbs) ... Except MX

160 kg (353 lbs) ... MX

Includes the weight of the rider, passenger, all cargo and all accessories

### **Maximum cargo weight:**

14 kg (30 lbs)

The weight of added accessories will reduce the maximum cargo weight you can carry.

## **Loading Guidelines**

Your motorcycle is primarily intended for transporting you and a passenger. You may wish to secure a jacket or other small items to the seat when you are not riding with a passenger.

If you wish to carry more cargo, check with your Honda dealer for advice, and be sure to read the information regarding accessories on page 6 .

Improperly loading your motorcycle can affect its stability and handling. Even if your motorcycle is properly loaded, you should ride at reduced speeds and never exceed 130 km/h (80 mph) when carrying cargo.