

(Ref.No.) Description	Function
(6) Right control button	Use this button for the following purposes. <ul style="list-style-type: none"> • To adjust time • To switch blinking of the immobilizer system (HISS) indicator (except MX, BR type) • To indicate/not indicate fuel mileage meter (except MX, BR type) • To change unit of speedometer and fuel mileage meter (E type only)
(7) Left control button	Use this button for the following purposes. <ul style="list-style-type: none"> • To adjust time • To switch blinking of the immobilizer system (HISS) indicator (except MX, BR type) • To change indication of tripmeter A and B • To reset tripmeter