

(Ref.No.) Description	Function
(8) Multi-function display	The display includes the following functions; This display shows the initial display (page 18).
Low oil pressure indicator/Coolant temperature indicator/ PGM-FI indicator	Lights the low oil pressure indicator and/or coolant temperature indicator and/or PGM-FI indicator to notify that there is abnormality in engine oil pressure and/or coolant temperature and/or PGM-FI (Programmed Fuel Injection) system when the malfunction indicator lights. See page 20 – 22 .
Speedometer	Shows riding speed (page 23).
Odometer	Shows accumulated mileage (page 23).
Tripmeter	Shows mileage per trip (page 23).
Fuel mileage meter (Except MX, BR type)	Shows the fuel mileage in every approximately 15 seconds (page 24).
Digital clock	Shows hour and minute (page 26).