


Steering Lock

The motorcycle has a steering lock (1) on the steering column under the headlight case.

To lock the steering, turn the handlebar all the way to the right (general type: right or left), insert the steering lock key (general type: ignition key) in the lock, turn the key 60° to the left and press in, turn the key back to the original position and remove the key. To unlock the steering, perform the locking sequence in the reverse order.



Bloqueador del manubrio

La motocicleta está provista de un bloqueador del manubrio (1) en la columna de dirección debajo de la caja de faro.

Para bloquear la dirección, gire el manubrio hacia la derecha hasta el fondo (en el caso del modelo general: hacia la derecha o hacia la izquierda), inserte la llave de bloqueo de la dirección (para el modelo general: llave del encendido) en el interruptor, gire la llave 60° hacia la izquierda y prénsela, luego, ponga la llave en la posición original y retire la llave. Para desbloquear la dirección, efectúe la operación de bloqueo en orden inverso.

