

# Maintenance Schedule

## MAINTENANCE SCHEDULE – REGULAR OFF-ROAD USE (NON-COMPETITION)

ITEMS	FREQUENCY	Which ever Comes First ↙	Initial Maintenance	Regular Maintenance Interval					Refer to Page:
			mi	600	1,200	1,800	2,400		
			km	1,000	2,000	3,000	4,000		
NOTE	Month	1	6	12	18	24			
* FUEL LINE					I		I	41	
** FUEL STRAINER SCREEN					C		C	42	
* THROTTLE OPERATION					I		I	55	
AIR CLEANER	(NOTE 1)			C	C	C	C	51	
CRANKCASE BREATHER				I	I	I	I	53	
SPARK PLUG				I	I	I	I	61	
* VALVE CLEARANCE			I	I	I	I	I	66	
ENGINE OIL			R	R	R	R	R	44	
ENGINE OIL FILTER			R	R	R	R	R	44	
* DECOMPRESSOR SYSTEM			I	I	I	I	I	–	
** ENGINE IDLE SPEED			I	I	I	I	I	134	
RADIATOR COOLANT	(NOTE 3)				I		R	48,50	
* COOLING SYSTEM			I	I	I	I	I	49	
* SECONDARY AIR SUPPLY SYSTEM	(NOTE 2)				I		I	–	
TRANSMISSION OIL			R	R	R	R	R	47	
DRIVE CHAIN	(NOTE 1)		I, L	I, L: every 300 mi (500 km) or 3 months				94,96	
DRIVE CHAIN SLIDER				I	I	I	I	96	
BRAKE FLUID	(NOTE 3)			I	I	I	I	87	
BRAKE PADS WEAR				I	I	I	I	89	
BRAKE SYSTEM			I	I	I	I	I	87	
* HEADLIGHT AIM					I		I	101	
CLUTCH SYSTEM			I	I	I	I	I	56	
SIDE STAND					I		I	93	
* SUSPENSION					I		I	82,83	
* SPARK ARRESTER				C: every 1,000 mi (1,600 km) or every 100 operating hours				65	
* NUTS, BOLTS, FASTENERS			I		I		I	98,154-156	
** WHEELS/TIRES			I	I	I	I	I	90,91	
** STEERING HEAD BEARINGS			I		I		I	97	

\* Should be serviced by your Honda dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 168).

\*\* In the interest of safety, we recommended these items be serviced only by your Honda dealer.

Summary of Maintenance Schedule Notes and Procedures;

### NOTES:

1. Service more frequently when ridden in wet or dusty conditions.
2. USA and Canada type only.
3. Replace every 2 years. Replacement requires mechanical skill.