

Index

A

- accessories4
- adjustments,
 - carburetor140
 - chassis143
 - control freeplay54, 56, 60, 88
 - for competition111
 - gearing144
 - personal fit146
 - steering damper141
 - suspension, front112
 - suspension, rear126
 - suspension, track conditions130
 - tire selection94
- after competition maintenance33
- air cleaner51
- air pressure,
 - front suspension112
 - tires93
- apparel, protective2
- appearance care108
- authorized manuals174

B

- basic operation13
- before riding9
- between motos & practice maintenance33
- brakes,
 - fluid level89
 - lever, front adjustment88
 - pad wear91
 - pedal height88
- break-in guidelines21

C

- capacity, fuel41
- carburetor,
 - adjustment140
 - circuit functions134
 - components134
 - disassembly/assembly137
 - idle speed140
 - removal136
- care, appearance108
- chain drive96
- chassis adjustment for track conditions143
- choke knob15
- cleaner, air51
- cleaning, appearance care108
- clutch system, adjustment56
- competition logbook167
- consumer information173
- contacting Honda177
- controls, operating7
- coolant48
- customer service178
- cylinder system77

D

- damping adjustments,
 - front112
 - rear127
- dealer, your Honda178
- diagram, wiring171
- drive chain96

E

- engine,
 - flooded16
 - idle speed140
 - number158
 - oil43
 - pinging41
 - starting15
 - stop button16
 - stopping16
 - won't start152
- environment, protecting151

F

- filter,
 - air51
 - fuel42
 - oil44
- flooded engine, starting16
- fork,
 - front suspension adjustment112
 - front suspension inspection84
 - oil recommendation86
- front brake lever adjustment88
- front suspension maintenance84
- fuel,
 - filter42
 - line41
 - oxygenated166
 - recommendation41
 - refueling41
 - system41
 - tank capacity41
 - valve15