

Transmission Oil

Transmission Oil



Notes.

The engine, the muffler and the exhaust pipes are extremely hot after stopping the engine.

Transmission oil should be checked as part of your pre-ride inspection.

1. To check transmission oil, hold bike in an upright position. Ensure bike is on level ground.
2. Remove check bolt.
3. The oil level should be up to the lower threads of the check bolt hole.
4. To add oil, remove filler cap and pour in the recommended transmission oil until it is at the correct level.

