

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]					Refer to pages
			× 1,000 km	1	4	8	12	
			× 1,000 mi	0.6	2.5	5	7.5	
		MONTHS		6	12	18		
* FUEL LINE				I	I	I	—	
* FUEL STRAINER SCREEN				C	C	C	—	
* THROTTLE OPERATION				I	I	I	64	
AIR CLEANER		NOTE (2)		C	C	C	56	
CRANKCASE BREATHER		NOTE (3) (4)		C	C	C	—	
SPARK PLUG				I	R	I	60–61	
* VALVE CLEARANCE				I	I	I	62–63	
ENGINE OIL				R	R	R	57–59	
** ENGINE OIL STRAINER SCREEN						C	—	
* CAM CHAIN TENSION				A	A	A	66	
* ENGINE IDLE SPEED				I	I	I	65	