


Recoil Starting: (CT 200)

If the engine does not start with the electric starter, use the recoil starter.

1. Raise the decompressor lever (1) up to the DECOMP position.
2. To use the recoil starter, follow the steps under Preparation and 1—3 under Normal Air Temperature. (See page 82)

NOTE:

- * A quick vigorous pull on the starter rope (2) will be the most effective way to start.



Arranque de retroceso: (CT200)

Si el motor no arranca con el motor eléctrico, utilizar el arrancador de retroceso.

1. Elevar la palanca del descompresor (1) hacia la posición DECOMP.
2. Para utilizar el arrancador de retroceso, seguir los pasos indicados en el apartado Preparación y los puntos 1 al 3 en temperatura normal del aire. (pág. 82)

NOTA:

Un tirón rápido de la cuerda del arrancador (2) será el método más rápido de efectuar el arranque.

