



# Switches

## Headlight dimmer switch

-  : High beam
-  : Low beam

## Passing light control switch

Flashes the high beam headlight.



## Handle grip heater switch

 P.42



## Turn signal switch

- The turn signal will automatically stop when you complete the turn.
- When used for a lane change, the turn signal is automatically stopped in 7 seconds or after riding 120 m (131 yards).
- ▶ You can manually cancel the turn signal by pressing the switch in.
- ▶ In some cases, the timing at which the turn signal stops is changed.
- ▶ Always use the recommended tyres to ensure correct automatic cancellation operation.



## Horn button

