


Switches *(Continued)*



SELECT button

SET button

These buttons used to operate the i-multi-information display. ➔ P.22

AUDIO power button

MODE button

MUTE button

VOLUME button

TRACK button

These buttons used to operate the audio system. ➔ P.48

 **TCS (Traction Control System) off switch**

Press and hold to turn the TCS on and off.

▶ The TCS off indicator comes on when TCS is turned off.