

Audio System Trouble

Symptom	Cause/remedy
Sounds skip Noises mix	Depending on the <i>Bluetooth</i> ® device and applications software you use, an audio file may not be played normally after receiving a telephone call, etc. Change the audio mode (➤ P. 50) or turn off the power to the audio system and then turn it on again. If the skipping of sounds or mixing of noises continues, check the status of your <i>Bluetooth</i> ® device.
	Reset the pairing information before re-pairing. ➤ P. 51, 54
	Check the recommended specifications. ➤ P. 46
No or inaccurate display	Depending on the audio device and the audio file, nothing may be displayed or the display may be inaccurate in some cases.
	Check the information on available tags. ➤ P. 47
	When the information in an audio file such as the artist name and track title is in a non-compliant tag format, it may be indicated by “..” or no information will be shown.