

The immobilizer system (HISS) indicator can continue flashing every 2 seconds for 24 hours with the ignition switch OFF. After that, the indicator automatically switches off.


To activate the indicator function, carry out the following:

1. Turn the ignition switch ON.
2. Have the odometer displayed (page 24).
3. Press the RESET button (1) for more than 2 seconds.

The immobilizer system (HISS) indicator (2) will flash once to indicate that the function has been activated.

4. Turn the ignition switch OFF. As you pull out the key, the indicator will start to blink.

When the ignition switch is turned ON again, the indicator function will be cancelled.



- (1) RESET button
(2) Immobilizer system (HISS) indicator