

Front Suspension Inspection

Check the front fork assembly by locking the front brake and pumping the fork up and down vigorously.

Suspension action should be smooth and there must be no oil seepage.

Carefully inspect all front suspension fasteners for tightness. This includes the attachment points of the fork tubes, brake components and handlebar.

WARNING: Contact your Honda dealer for repair of any steering or front suspension wear or damage.

Do not operate the motorcycle with loose, worn, or damaged steering or front suspension, as handling will be adversely affected.

