


Headset/speaker Mode Button

If you use the headset, push this button. The display will indicate “” (headset). To hear sound through the speakers, push this button again.



Intercom Volume Control Knob

⚠ WARNING


- *Some local governments prohibit the operator from using a headset; always obey applicable laws and regulations.*

To communicate with the passenger using the intercom, turn this knob clockwise.

Turning this knob further increases intercom volume. When not using the intercom system, turn off this knob.

NOTE:

- The auto volume control does not function for the intercom system
- Turn this knob only high enough for adequate volume; if turned too high, there may be “feed back” from the fairing speakers.



Front Headset
Terminal

