
VENTILATION

This motorcycle has an adjustable windshield and foot warmer ventilation as well as ventilation louvers in the fairing.

▲ WARNING

- ***Making ventilation adjustments while riding can result in an accident. Adjust only when the vehicle is stopped.***

Windshield Ventilation (*SE only*)

To direct fresh air, open the louver by operating the lever.

