

Parts Location

Rear brake fluid reservoir ➔ P.54

Fuse box ➔ P.83

Battery ➔ P.50

Front brake fluid reservoir ➔ P.54

Throttle grip ➔ P.64

Engine oil fill cap/dipstick ➔ P.51

Spark plug ➔ P.66

Engine oil drain bolt ➔ P.53

