

GASOLINE AND OIL

**DO NOT PRE-MIX GASOLINE AND OIL.
FILL THE FUEL TANK WITH GASOLINE
ONLY.**

**FILL THE OIL TANK WITH TWO-CYCLE
MOTOR OIL.**

The proper amount of oil is supplied to the sliding surfaces of crankshaft, right crankshaft bearing, connecting rod, piston and cylinder wall by an oil pump.

Engine Oil

Recommended oil

Use two-cycle motor oil.

Temperature	Viscosity
Above 68°F (20°C)	SAE 30, 10W30, 20W
14°F (-10°C) to 68°F (20°C)	SAE 10W30
Below 14°F (-10°C)	SAE 5W, 10W

NOTE:

**If two-cycle motor oil is not available,
use other premium quality motor oil of
the recommended viscosity.**