



SHUTTING OFF THE ENGINE



Close the throttle.



Turn the ignition key to the
“OFF” position.