

Rif. No.	Description	Function
10	Tripmeter reset knob	Zero (0) the temporary odometer by pressing the button.
11	Tripmeter	Indicates the number of kilometers completed on the trip.
12	Standby indicator (@125/150 ES)	Flashes by the idle stop system when the idle stop is functioned.