

## **BREAK-IN PROCEDURE**

Maximum continuous engine speed during the first 1,000 km (600 miles) must not exceed 6,000 min<sup>-1</sup> (rpm).

Avoid full throttle operation, and select your gear changes to spare the engine undue stress. Careful break-in operation during the initial mileage period will measurably extend the service life of the engine.

---

## **PROCÉDURE DE RODAGE**

Le régime continu maximal du moteur ne devra pas dépasser 6 000 tr/mn pendant les 1 000 premiers kilomètres.

Éviter d'ouvrir les gaz à plein, et choisir les vitesses de façon à éviter toute tension inutile au moteur. Le soin apporté au rodage pendant la période initiale de fonctionnement allongera sensiblement la durée de vie du moteur.