

MAINTENANCE

page	
108	MAINTENANCE
108	THE IMPORTANCE OF MAINTENANCE
109	MAINTENANCE SAFETY
110	SAFETY PRECAUTIONS
111	MAINTENANCE SCHEDULE
114	TOOL KIT
115	SERIAL NUMBERS
116	COLOUR LABEL
117	ENGINE OIL
123	CRANKCASE BREATHER
124	SPARK PLUGS
127	FINAL DRIVE OIL
129	THROTTLE OPERATION
130	COOLANT
131	AIR CLEANER
132	FRONT AND REAR SUSPENSION INSPECTION
133	SIDE STAND
134	WHEEL REMOVAL
141	BRAKE PAD WEAR

page	
143	BATTERY
145	FUSE REPLACEMENT
149	BRAKELIGHT SWITCH ADJUSTMENT
150	BRAKE LOCK OPERATION
151	BULB REPLACEMENT
160	CLEANING
165	STORAGE GUIDE
165	STORAGE
167	REMOVAL FROM STORAGE
168	SPECIFICATIONS
173	CATALYTIC CONVERTER