


LOWER FAIRING

Removal :

1. Remove the screws (1).
2. Remove the tachometer cable (2) from cable guide.
3. Remove the carburetor drain tube (3) from guide hole.



- (1) Screw
(2) Tachometer cable
(3) Tube