


## Front/Rear Turn Signal Bulb

1. Remove the turn signal lens (1) by removing screw (2).
2. Pull out the turn signal bulb (3).
3. Install a new bulb in the reverse order of removal.



- (1) Lens
- (2) Screw
- (3) Bulb