

(Ref.No.) Description	Function
(17) Parking brake indicator (red)	It lights as a reminder that you have not released the parking brake.
(18) Anti-lock brake system (ABS) indicator (red) (NSS250EX)	This light normally comes on when the ignition is turned ON, and goes off after you ride the scooter at speed above 10 km/h (6 mph). If there is a problem with the Anti-lock Brake System, this light comes on and remains on (see page 37).
(19) High beam indicator (blue)	Lights when the headlight is on high beam.