


TOOL KIT

The tool kit (1) is in the center compartment below the inner mat (2).

To access the tool kit, remove the mat.

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- Spark plug wrench
- 10 × 12 mm Box end wrench
- 8 mm Open end wrench
- 10 × 12 mm Open end wrench
- 14 × 17 mm Open end wrench
- Standard/Phillips screwdriver
- Screwdriver handle
- Pin spanner
- Extension bar
- Tool bag



(1) Tool kit

(2) Mat