

MAINTENANCE

page

137 MAINTENANCE

- 137 THE IMPORTANCE OF
MAINTENANCE
- 138 MAINTENANCE SAFETY
- 139 SAFETY PRECAUTIONS
- 140 MAINTENANCE SCHEDULE
- 143 TOOL KIT
- 144 SERIAL NUMBERS
- 145 COLOUR LABEL
- 146 AIR CLEANER
- 147 BELT CASE AIR CLEANER
- 150 CLIP
- 152 CRANKCASE BREATHER
- 153 ENGINE OIL
- 160 SPARK PLUG
- 163 THROTTLE OPERATION
- 164 COOLANT
- 165 FRONT AND REAR SUSPENSION
INSPECTION
- 166 SIDE STAND
- 167 BRAKE PAD WEAR
- 169 BRAKE LOCK OPERATION
- 170 BATTERY

page

- 173 FUSE REPLACEMENT
- 176 BULB REPLACEMENT

184 CLEANING

189 STORAGE GUIDE

- 189 STORAGE
- 191 REMOVAL FROM STORAGE

192 SPECIFICATIONS

196 CATALYTIC CONVERTER