

(Ref.No.) Description	Function						
(12) Tachometer red zone	<p>Never allow the tachometer needle to enter the red zone, even after the engine has been broken in.</p> <p>NOTICE</p> <p>Running the engine beyond recommended maximum engine speed (the beginning of the tachometer red zone) can damage the engine.</p>						
(13) Shift information display (NSS250A)	<p>The display includes the following functions; This display shows the initial display (page 27).</p> <table border="1" data-bbox="154 529 1310 840"> <tbody> <tr> <td data-bbox="154 529 531 632">“M” Icon mark</td> <td data-bbox="531 529 1310 632">Displays when the 7-speed manual mode is selected (page 37).</td> </tr> <tr> <td data-bbox="154 632 531 736">“A” Icon mark</td> <td data-bbox="531 632 1310 736">Displays when the 7-speed automatic mode is selected (page 37).</td> </tr> <tr> <td data-bbox="154 736 531 840">Shift indicator</td> <td data-bbox="531 736 1310 840">Shows the gear position when the 7-speed manual or automatic mode is selected (page 36).</td> </tr> </tbody> </table>	“M” Icon mark	Displays when the 7-speed manual mode is selected (page 37).	“A” Icon mark	Displays when the 7-speed automatic mode is selected (page 37).	Shift indicator	Shows the gear position when the 7-speed manual or automatic mode is selected (page 36).
“M” Icon mark	Displays when the 7-speed manual mode is selected (page 37).						
“A” Icon mark	Displays when the 7-speed automatic mode is selected (page 37).						
Shift indicator	Shows the gear position when the 7-speed manual or automatic mode is selected (page 36).						