


## To Lock the Ignition Switch

1. Turn the ignition switch to the OFF or LOCK position.
2. Leave the operating range with the Honda smart card key (1). The ignition switch illumination and all turn signals flash twice and then the ignition switch locks.

When the Honda smart card key system does not work properly, see page 72 .



(1) Honda smart card key