



When you leave your scooter in a restaurant or a gas station, lock the steering and take the Honda smart card key (1) with you. Make sure the all turn signals flash twice at this time.



(1) Honda smart card key

Anybody can unlock the ignition switch and start the engine if your card key is within operating range of your scooter, even if you are on the other side of a wall or window. If you are away from your scooter but your card key is still within operating range, turn off the Honda smart card key system. See page 63 for Switching Honda Smart Card Key System.



You should always keep the Honda smart card key on your person.

Anyone in possession of the card key can start the engine and unlock the ignition switch, front seat lock and console box lock if the card key is within operating range.